PREVENT FIRES, PROTECT THE HOME

Kitchen Safety

Check the U.S. Consumer Product Safety Commission website (www.cpsc.gov) for recent recalls of any appliances in your home.

The outlets in your kitchen should have Ground Fault Circuit Interrupter (GFCI) protection. Remember to test GFCIs monthly to ensure they are functioning properly.

Unplug all countertop appliances after use. Do so by pulling on the plug, not the cord, to avoid damage to the cord.

Never leave food that is cooking unattended.

Keep all countertop appliances and their cords away from the sink and heat sources, like the stovetop.